SRL-579A Blacklight User Manual

I. Technical Date:

Name:	Blacklight
Type:	G007UA(SRL-579A)
Lamp:	18W Tube
Voltage:	AC 240V 50Hz 20VA
Fuse:	0.5A
Weight:	2.8 kgs
Measurement:	L: 710 x W: 130 x H: 100 mm

II. Operation:

1. Open the package and ensure the fitting is undamaged.
2. Unscrew the mesh and place the lamp into the socket. Then, fix mesh and tighten the screws.
3. Use M8 screw to fix the handle on 2 sides of the light. Then, hang the unit on the ceiling and fix it by using the other 2 M8 screws.
4. Check and make sure that the rated power corresponds to the main supply.
5. Unplug from power source when not being used.
6. If the bulb or fuse is damaged, please replace with bulb or fuse of the same specification.

III. Bulb Replacement

1. Before opening unit, make sure that the unit is cool and is not connected to any power source.
2. Remove the screw on the access door on the top of the unit and open the access door.
3. Replace with the bulb of the same specification.
4. Close the access door and tighten the screws.

IV. Caution:

1. Replace bulb and fuse with the same type bulb and fuse.
2. To prevent electric shock do not remove cover or change lamps when unit is connected to an AC power source.
3. Never open unit when hot. Never use in a damp or dusty environment. Indoor use only. Refer servicing to qualified personnel.
4. This unit must be earthed.
5. Ambient temperature should not exceed 35^0C
6. We recommend that the unit is not used continually and is sited so that people are not exposed to UV light at close range for a continuous period.